

Installation Instructions:

TO BE SOLD ONLY WITH INSTALLATION INSTRUCTIONS:

1. Turn off power before installing or removing connectors.
2. Strip #14 and larger wires 3/8"-Strip 16 gauge and smaller wires 7/16".
3. Align any frayed strands or conductors.
4. Pre-twisting unnecessary. Hold stripped wires together with ends even.
5. Screw on connector-push wires firmly into connector when starting.

Voltage Rating: 300V max.

COPPER TO COPPER ONLY: (DO NOT US ON ALUMINUM)

Temperature Rating: 105°C, 221°F max.



Heyco Products, Inc.
1800 Industrial Way North
Toms River, NJ 08755

Toll Free: 800.528.4182
Toll Free Fax: 800.358.7904
Phone: 732.286.1800
Fax: 732.244.8843

Visit or Website at:
www.heyco.com

WIRE CONNECTORS (YELLOW) PART# 2952 84-Y

Listed as PRESSURE-TYPE wire connector on the following solid and/or stranded wire combinations.

300V MAX.

2 #14 W/1 16# W/1 to 3 #22	1 #12 W/1 to 3 #14, 16 or 18	4 #14 W/1 #16 or #18	1 #8
3 #14 W/1 #18 W/1 #20 or #22	1 #14 W/4 #16 or #18	3 #16 W/1 or 2 #18, #20 or #22	1 #10
1#16 W/1 #18 W/2 or 3 #20 or #22	2 #12 W/1 or 2 #14	1 #10 W/1 #12 W/1 #14 or #16	1 to 3 #12
1#16 W/1 #18 W/3 or 4 #22	2 #12 W/1 #16 or #18	1 #10 W/1 #12 W/1 or 2 #18	1 to 3 #14
3 #16 W/1 #18 W/1 #20 or #22	1 #14 W/1 to 3 #16 or #18	1 #10 W/1 #14 W/2 #16	2 to 5 #16
1#18 W/2 #20 W/3 #22	2 #14 W/1 to 3 #16,18 or #20	1 #10 W/1 #14 W/2 to 3 #18	3 to 6 #18
2#18 W/1 #20 W/3 #22	3 #14 W/1 or 2 #16	1 #10 W/2 #14 W/1 #16	1 #10 W/1 #12
3 TO 6 #18	3 #14 W/1 or 2 #18 or #20	1 #10 W/1 #16 W/1 or 2 #18	1 #10 W/3 or 4 #16



WIRE CONNECTORS (YELLOW) PART# 2952 84-Y

Listed as PRESSURE-TYPE wire connector on the following solid and/or stranded wire combinations.

300V MAX.

2 #14 W/1 16# W/1 to 3 #22	1 #12 W/1 to 3 #14, 16 or 18	4 #14 W/1 #16 or #18	1 #8
3 #14 W/1 #18 W/1 #20 or #22	1 #14 W/4 #16 or #18	3 #16 W/1 or 2 #18, #20 or #22	1 #10
1#16 W/1 #18 W/2 or 3 #20 or #22	2 #12 W/1 or 2 #14	1 #10 W/1 #12 W/1 #14 or #16	1 to 3 #12
1#16 W/1 #18 W/3 or 4 #22	2 #12 W/1 #16 or #18	1 #10 W/1 #12 W/1 or 2 #18	1 to 3 #14
3 #16 W/1 #18 W/1 #20 or #22	1 #14 W/1 to 3 #16 or #18	1 #10 W/1 #14 W/2 #16	2 to 5 #16
1#18 W/2 #20 W/3 #22	2 #14 W/1 to 3 #16,18 or #20	1 #10 W/1 #14 W/2 to 3 #18	3 to 6 #18
2#18 W/1 #20 W/3 #22	3 #14 W/1 or 2 #16	1 #10 W/2 #14 W/1 #16	1 #10 W/1 #12
3 TO 6 #18	3 #14 W/1 or 2 #18 or #20	1 #10 W/1 #16 W/1 or 2 #18	1 #10 W/3 or 4 #16



Installation Instructions:

TO BE SOLD ONLY WITH INSTALLATION INSTRUCTIONS:

1. Turn off power before installing or removing connectors.
2. Strip #14 and larger wires 3/8"-Strip 16 gauge and smaller wires 7/16".
3. Align any frayed strands or conductors.
4. Pre-twisting unnecessary. Hold stripped wires together with ends even.
5. Screw on connector-push wires firmly into connector when starting.

Voltage Rating: 300V max.

COPPER TO COPPER ONLY: (DO NOT US ON ALUMINUM)

Temperature Rating: 105°C, 221°F max.



Heyco Products, Inc.
1800 Industrial Way North
Toms River, NJ 08755

Toll Free: 800.528.4182
Toll Free Fax: 800.358.7904
Phone: 732.286.1800
Fax: 732.244.8843

Visit or Website at:
www.heyco.com